

**Wireless Multi-Device Keyboard
with Touchpad**

LIMITLESS™


GETTING STARTED

Please charge the keyboard for 2-3 hours or until low battery indicator light turns off before first use.

Please read this Quick Start Guide carefully before you start using this product.

WHAT'S INCLUDED

- (1) Wireless Multi-Device Keyboard
- (1) 40" Charging Cable



COMPONENTS

1. Device Holding Tray
2. Keyboard
3. Functional Keys
4. On/Off Switch
5. Indicator Lights
6. Touchpad
7. Mouse Keys

INDICATOR LIGHTS KEY


- Caps Lock Indicator
- Power/Low Battery Indicator
- Pairing Indicator
- Charging Indicator

FUNCTIONAL KEYS

Symbol	Function	Fn+Key	Symbol	Function	Fn+Key
	Home (iOS/Android) Browser (Windows)	Esc		Previous track	F7
	Brightness down	F1		Play/pause	F8
	Brightness up	F2		Next track	F9
	Select all	F3		Mute	F10
	Copy	F4		Volume down	F11
	Paste	F5		Volume up	F12
	Cut	F6		Screen lock	Del

PAIRING & MULTI-PAIRING

1. Turn on the keyboard using the sliding switch on the side. While the blue pairing indicator light is illuminated, press and hold the Fn+C1 for 3 seconds. The keyboard is in pairing mode while the blue indicator light is flashing.
2. Power on the device that's being paired to the keyboard, navigate to settings/system preferences and select Bluetooth. Make sure the device is discoverable.
3. In the Bluetooth device searching list, select "Limitless Keyboard" to connect.
4. Once connected successfully, the keyboard is ready for use.
5. Repeat the steps to pair an additional device. Hold Fn+C2 in Step 1 while pairing the secondary device.



LIMITLESS™

Designed in USA. Made in China.
All rights reserved.
Limitless™ is a trademark of Limitless Innovations, Inc. Design and specifications subject to change without notice. Products may vary from images shown. Accessories sold separately.

LimitlessInnovations.com
Support@LimitlessInnovations.com
(855) 843-4828

Limitless Innovations, Inc.
4800 Metalmaster Way
McHenry, IL 60050

© Limitless Innovations, Inc.



SWITCHING BETWEEN DEVICES

Switch between paired devices by selecting the appropriate assigned Bluetooth key – “Fn+C1” or “Fn+C2”.

The keyboard can pair up to 2 different Bluetooth devices.

Note: The time between switching devices will take approximately 2-4 seconds.

LOW BATTERY REMINDER

If the blue indicator is flashing, please use the included Type-C charging cable to charge the keyboard. While charging, the light will illuminate red. The light will turn off once the keyboard is fully charged.

POWER MANAGEMENT

The keyboard will go into sleep mode after 20 minutes if it is not in use while powered on. Press any key to wake up the keyboard. It will take 3-5 seconds to reconnect to the device selected.

TOUCHPAD ACTION KEY

WINDOWS, iOS, ANDROID

Function	Action
Move cursor	One finger slide
Scroll on parallel or vertical	Two fingers slide

WINDOWS

Function	Action
Zoom in	Slide to two sides from center
Zoom out	Slide to center from two sides
Open Cortana	Three finger click
Open background window	Three fingers slide up
Show desktop	Three fingers slide down
Backward	Three fingers slide to left
Forward	Three fingers slide to right
Click once or click twice	One/two finger(s) click once or twice

TECH SPECS

Keyboard size: 14.49 in x 6.38 in x (0.35-0.79) in

Working distance: ~10m

Lithium battery capacity: 180mAh

Working voltage: 3.2~4.2V

Operation current: <2mA

Standby current: <0.5mA

Sleep current: <50uA

Sleep time: 20 minutes

Awaken way: click any key to awaken

Recharge Time: 2 hours

Battery Life: 1 year



CONTINUED USAGE

It is recommended to keep the Wireless Multi-Device Keyboard plugged into a power source whenever possible to ensure readiness when away from an outlet.

Notes: To switch between operating systems while the keyboard is already connected, press Fn and Q(iOS), W(Android) or E (Windows) together.

*For iPhone: When using the touchpad, please ensure that the auxiliary touch function of the iPhone is turned on by going to **Settings - Accessibility - Touch - Assistive Touch - On.***

SAFETY INFORMATION

By using the Limitless Wireless Multi-Device Keyboard, you hereby agree that Limitless Innovations, Inc., an Illinois corporation and its affiliates (“Limitless”) shall have no liability for any losses associated with property damage, personal injury or loss of life that are incurred by you or by any third party in connection with or relating in any manner whatsoever to your use of the Limitless Wireless Multi-Device Keyboard. By using the Limitless Wireless Multi-Device Keyboard, you hereby agree at all times to comply fully with all safety warnings, operating instructions and general safety information in this user manual. By using the Limitless Wireless Multi-Device Keyboard, you further agree to hold harmless Limitless, (and Limitless’ officers, directors, shareholders and employees) in connection with any losses sustained by you (including, without limitation, losses arising in whole or in part from property damage, personal injury or loss of life) relating in any manner whatsoever to your use of the Limitless Wireless Multi-Device Keyboard.

WARNING

- Keep the Limitless Wireless Multi-Device Keyboard away from liquid or humid environments, saunas, swimming pools, steam rooms, and rain.
- Do not expose the Wireless Multi-Device Keyboard at too high or too low temperature conditions.
- Keep the Limitless Wireless Multi-Device Keyboard out of sunlight for prolonged periods of time.
- Do not put the Limitless Wireless Multi-Device Keyboard near any heat sources.

SCAN TO LEARN MORE:

