


TotalBoost Mini™

Quick Start Guide



WHAT'S INCLUDED

- (1) TotalBoost Mini
- (1) Microfiber Pouch
- (3) Charging Adapters: Micro, Lightning, & Type-C
- (1) 24in Type-C to USB Charging Cable



COMPONENTS

1. Digital Display
2. Flashlight Power Button
3. Flashlight
4. Adapter Cavity
5. Type-C Input/Output
6. Adapter Release Switch

COMPATIBILITY



Type-C

Samsung, Microsoft, Google, LG, Huawei, and More



Lightning

iPhones & Most Apple Devices



Micro

Tracfores, Speakers, Cameras, Power Banks, & More



CHARGING & RECHARGING

Checking the Battery Level

Press the Flashlight Power Button to display the current battery percentage on the Digital Display.

Recharging the TotalBoost Mini

Plug the included 24in Type-C to USB Charging Cable into the Type-C Input/Output and into a USB charger (USB charger not included).

USING THE FLASHLIGHT

Press and hold the Power Button to turn the Flashlight on/off.

REMOVING AN ADAPTER

Push upwards on the Adapter Release Switch to release the installed Charging Adapter and pull to remove.

USING THE POWER BANK

1. Select the Charging Adapter that is compatible with your device.
2. Firmly install the Charging Adapter into the Charging Cavity until it clicks in place.
3. Plug the Charging Adapter into the device.
4. The device will begin to charge.

NOTE:

Some phone cases may be too thick and prohibit a successful connection to the Charging Adapter. If the connected device does not begin to charge:

- A. Check the battery capacity.
- B. Remove the case from the mobile phone.



TECH SPECS

Model: LIM-TBSTM4-XXXX

Battery Capacity: 4,000mAh

Recharging Time (From 0%): 2-3 Hours

Type-C Input: 5V/2.4A

Type-C Output: 5V/2.4A

Adapter Output: 5V/2.4A

Flashlight: 25 Lumens

Product Dimensions: 3.15" x 2.28" x 1.10"

Weight: 0.23 lb

SAFETY INFORMATION

By using the Limitless TotalBoost Mini, you hereby agree that Limitless Innovations, Inc., an Illinois corporation and its affiliates (“Limitless”) shall have no liability for any losses associated with property damage, personal injury or loss of life that are incurred by you or by any third party in connection with or relating in any manner whatsoever to your use of the Limitless TotalBoost Mini. By using the Limitless TotalBoost Mini, you hereby agree at all times to comply fully with all safety warnings, operating instructions and general safety information in this user manual. By using the Limitless TotalBoost Mini, you further agree to hold harmless Limitless, (and Limitless’ officers, directors, shareholders and employees) in connection with any losses sustained by you (including, without limitation, losses arising in whole or in part from property damage, personal injury or loss of life) relating in any manner whatsoever to your use of the Limitless TotalBoost Mini.

WARNING

- Limitless TotalBoost Mini is **NOT** a toy and should be kept away from children.
- Do **NOT** use the Limitless TotalBoost Mini near a magnetic or electric field.
- Do **NOT** use the Limitless TotalBoost Mini in direct sunlight or extreme heat for extended periods of time.
- Do **NOT** use the Limitless TotalBoost Mini if it has been damaged and/or modified.
- Do **NOT** subject the Limitless TotalBoost Mini to harsh chemicals.
- Do **NOT** submerge the Limitless TotalBoost Mini or its accessories in water.
- **CAUTION:** Risk of fire and burns. Do **NOT** open, crush, heat above 140° F (60° C) or incinerate. Follow manufacture’s instructions.
- Do **NOT** insert any foreign objects into the openings or port of the Limitless TotalBoost Mini.

- Do **NOT** charge the Limitless TotalBoost Mini in high humidity conditions.
- Do **NOT** attempt to replace the battery as it is a non-serviceable part.
- Do **NOT** attempt to disassemble, repair, or open the Limitless TotalBoost Mini or its accessories in any way.
- Do **NOT** paint or apply coatings to the Limitless TotalBoost Mini as you might affect moving parts or damage internal components.
- Do **NOT** use third party power supplies or non-approved adapters with the Limitless TotalBoost Mini.
- Do **NOT** use at an altitude higher than 6,562 feet (2,000 meters).
- Batteries should be recycled or disposed of, as per state and local guidelines.

To view the complete user manual, please scan:



LIMITLESS™

All rights reserved. Limitless TotalBoost Mini™, TotalBoost Mini™, and Limitless™ are trademarks of Limitless Innovations, Inc. Design and specifications subject to change without notice. Products may vary from images shown. Accessories sold separately.

LimitlessInnovations.com

Support@LimitlessInnovations.com
(855) 843-4828

Limitless Innovations, Inc.
4800 Metalmaster Way
McHenry, IL 60050

© Limitless Innovations, Inc.



@LimitlessInnovations



/LimitlessInnov



/LimitlessInnov



/LimitlessInnov



Limitless Innovations