# LIMITLESS

# **LifeClock™**

User Manual



### **FEATURES**

- Digital Clock
- Day Calendar
- 21-Mode Alarm Clock
- 4-Mode Medicine Reminder
- · Digital Photo Frame
- USB Charger
- 5 Screen Layouts
- 10 Languages

### **SCAN**

to view the complete user manual




### SAFETY INFORMATION

By using the LifeClock, you hereby agree that Limitless Innovations, Inc., an Illinois corporation and its affiliates ("Limitless") shall have no liability for any losses associated with property damage, personal injury or loss of life that are incurred by you or by any third party in connection with or relating in any manner whatsoever to your use of the LifeClock. By using the LifeClock, you hereby agree at all times to comply fully with all safety warnings, operating instructions and general safety information in this user manual. By using the LifeClock, you further agree to hold harmless Limitless, (and Limitless' officers, directors, shareholders and employees) in connection with any losses sustained by you (including, without limitation, losses arising in whole or in part from property damage, personal injury or loss of life) relating in any manner whatsoever to your use of the LifeClock.

### WARNINGS

- The LifeClock is NOT a toy and should be kept away from children.
- Do **NOT** use the LifeClock near a magnetic or electric field.
- Do NOT use the LifeClock in direct sunlight or extreme heat for extended periods of time.
- Do NOT use the LifeClock if it has been damaged and/or modified.
- Do NOT subject the LifeClock to harsh chemicals.
- Do NOT submerge the LifeClock or its accessories in water.
- Do NOT store the LifeClock where temperatures will exceed 140° F (60° C).
- Do **NOT** insert any foreign objects into the port or openings of the LifeClock.
- Do NOT store the LifeClock in high humidity conditions.
- Do **NOT** attempt to replace the battery as it is a non-serviceable part.
- Do **NOT** attempt to disassemble, repair, or open the LifeClock or its accessories in any way.
- Do NOT paint or apply coatings to the LifeClock as you might affect moving parts or damage internal components.

### WHAT'S INCLUDED



# SATURDAY SATURDAY 11:20 AM 28 JANUARY 2022 Control Panel Kickstand Insert

DC Input

### **CONTROL PANEL**



Press this button at any time to have the current time read aloud using the voice announcement feature. **NOTE:** \*If the language is set to a language other than English, this button will turn the Screen display on/off.



- While on the home screen, use this button to cycle between the different screen interfaces.
- When navigating the Main Menu, use this button to select and save the values within the settings.



Press this button to navigate to the Main Menu or return to the home screen.







Use these buttons to navigate the Menu and change the values.

Language Set	<	English	>
Time Set	<	12:45:00	>
Date Set	<	01-30-2023	>
Time Mode	<	24-Hour	>
Date Mode	<	Month-Day-Year	>
Auto Dimming	<	Off	>
Volume Set	<	15	>
Alarm Set	<		>
Medicine Reminder	<		>
Factory Reset	<	LIM-LCLK-001	>

### **TECHNICAL SPECIFICATIONS**

Model Number: LIM-LCLK-001

Screen Size: 8-Inch IPS Full View

**Display Resolution:** 800x600

Power Consumption: 8W

USB Output: 5V / 2A

Supported Media: Music, Video, and Photo

Speakers: Dual 2W

Installation: Desktop, Wall-Mountable

Materials: Plastic, ABS

**Model Number:** 9.13" x 6.38" x 0.94"

**Weight:** 12 oz (0.75 lbs)



### SETTING UP THE LIFE CLOCK

### **Getting Started:**

Peal the film off the screen.

Connect the Wall Plug to an outlet and the DC Input.

The LifeClock will start up right away using the default settings.

# Set the date, time, dimmer, and volume to your preferences.

Press the MENU button.

Use the  $\bigcirc$  and  $\bigcirc$  buttons to navigate the menu.

Pres the OK button to enter the edit mode.

Use the  $\bigoplus$  and  $\bigoplus$  buttons to change values.

Press the OK button to confirm and save after each value is set.

Press the wend button to return to the main menu/home screen.

### LANGUAGES

- 1. English
- 2. Deutsch
- 3. Français
- 4. Español
- 5. Italiano
- 6. Português
- 7. Polski
- 8. Nederlands
- 9. Finnish
- 10. Magyar

### **TIME SET**

- 1. 24-Hour
- 2. 12-Hour

### **DATE SET**

- 1. Day-Month-Year
- 2. Month-Day-Year
- 3. Year-Month-Day

### **AUTO DIMMER**

- Off
- 2. Auto
- 3. Mid
- 4. Low

### **VOLUME SET**

- 1. Minimum: 00
- 2. Max: 30

### **SETTING THE ALARMS**

Press the button to set the alarm(s).

Use the  $\bigoplus$  and  $\bigoplus$  buttons to navigate the alarm menu until the desired alarm is highlighted. Press the  $\bigoplus$  button to edit.

A white underline will appear under the current segment that is being edited.

Press the OK button to confirm and save after each value is set.

Use the  $\bigoplus$  and  $\bigoplus$  buttons to switch to the next segment. Hours | Minutes | Off/On

### Alarm Off/On Settings

- Off (Never)
- Monday To Sunday (Every Day)
- Saturday To Sunday (Weekends)
- Monday To Friday (Weekdays)

Press the OK button to save. Repeat these steps to set additional alarms.

### **ALARM MODES**

- 1. Alarm1
- 2. Alarm2
- 3. Alarm3
- 4. Alarm4
- 5. Alarm5
- 6. Time for breakfast
- 7. Time for lunch
- 8. Time for dinner
- 9. Wake up
- 10. Doctor's appointment today
- 11. Time for a glass of water

- 12. Time for a cup of coffee
- 13. Walk the dog
- 14. Blood sugar test
- 15. Time for bed
- 16. Feed the dog
- 17. Insulin management time
- 18. Measure your Blood Pressure
- 19. Go to church
- 20. Water your plants
- 21. Appointment haircut

### TURNING OFF THE ALARM

Press any button to turn off the alarm, or wait 20 seconds and it will automatically shut off.

### **SETTING THE MEDICINE REMINDERS**

Press the button to set the medicine reminder(s).

Use the  $(\uparrow)$  and  $(\downarrow)$  buttons to change the time values.

Use the  $\bigoplus$  and  $\bigoplus$  buttons to switch to the next segment. Hours  $\mid$  Minutes

Press the OK button to confirm and save after each value is set.

Use the  $\bigcirc$  and  $\bigcirc$  buttons turn the reminder On/Off.

Use the  $\bigoplus$  and  $\bigoplus$  buttons turn the change the mode of the Medicine Reminder.

### **Reminder Modes:**

- Monday to Sunday (Everyday)
- Monday to Friday (Weekdays)
- Saturday to Sunday (Weekends)

Time To Take	Time:	<	12:00	>
Morning Medicine	Status:	<	Off	>
Morning Medicine	Mode:	<	Monday to Sunday	>
Time To Take	Time:	<	12:00	>
Afternoon Medicine	Status:	<	Off	>
Alternoon Medicine	Mode:	<	Monday to Friday	>
Time To Take	Time:	<	12:00	>
Evening Medicine	Status:	<	Off	>
Evering Medicine	Mode:	<	Saturday to Sunday	>
Time To Take	Time:	<	12:00	>
Night Medicine	Status:	<	Off	>
Might Medicine	Mode:	<	Monday to Sunday	>

\*The Status of the Medicine Reminder must be turned to "On" for the reminder to sound.

### **CHANGING THE SCREEN LAYOUT**

Press the OK button to cycle between the following interfaces.

Layout 1



Layout 2

	<u>s</u>	•	4	J	3 an	•	4	202	22▶
WEDNESDAY		SUN	MON	TUE	WED	THU			
Α	FTERN	OON			_		-	1	_
		3		5	-	7	-	9	
12:35		10	11	12	13	14	15	16	
		17	18	19	20	21	22	23	
••		****	24	25	26	27	28	29	30
23 .	Jan	Jan 2022	31						

Layout 3



28 DECEMBER 2022

Layout 4



Layout 5



### **INSTALLING THE LIFECLOCK**

### A. Install the Kickstand.

- O1. Align the Kickstand with the Kickstand Insert on the back of the LifeClock. The smooth side should be on the left.
- O2. Twist the Kickstand clockwise to lock it in place.

### B. Mount the LifeClock on the wall

O1. Use the Keyhole opening and a screw or nail to mount the LifeClock on the wall (hardware not included).



Kickstand

## **USING THE DIGITAL PHOTO FRAME**

 Copy photos and/or videos to a USB flash drive (flash drive not included).

**TIP:** Photos and videos should be in land-scape format, sized to 800x600 pixels for optimal viewing. Photos that are not in this proportion will be squished or warped to fit the display.

- Plug the flash drive into the USB Port on the side of the LifeClock.
- 3. The media will begin to play.
- 4. To return to the main screen interfaces, press the button.
- Reconnect a flash drive with photos to use the digital frame again.

### NOTE:

If an Alarm or Reminder goes off while the Digital Photo Frame Feature is being used, you will need to reinstall the USB Flash drive to resume the media play.



### **CHARGING A MOBILE DEVICE**

Plug a USB cable into the USB Output & into a device. The device will begin to charge.

# LIMITLESS

All rights reserved. Limitless LifeClock™, LifeClock™, and Limitless™ are trademarks of Limitless Innovations, Inc. Design and specifications subject to change without notice. Products may vary from images shown.

Accessories sold separately.

### LimitlessInnovations.com

Support@LimitlessInnovations.com | (855) 843-4828

Limitless Innovations, Inc. 4800 Metalmaster Way McHenry, IL 60050











@LimitlessInnovations

/LimitlessInnov

/LimitlessInnov

/LimitlessInnov

Limitless Innovations

© Limitless Innovations, Inc.