

TECH SPECS

Model: I IM-TBST-XXX

Battery Capacity: 10,000mAh Recharging Time (From 0%):

> Standard USB Adapter: 5-6 Hours 18W QC USB Adapter: 3-4 Hours

Type-C Input: PD 18W

5V/3A | 9V/2A | 12V/1.5A

Type-C Output: PD 20W

5V/3A | 9V/2.5A | 12V/1.87A

2x USB Output: QC 20W

5V/3A | 9V/2.5A | 12V/1.87A

Temperature Range (Operation):

-4°~95°F(-20°~+35°C)

Charge Operating Temperature:

32°~113°F (0°~+45°C)

Discharging Operating Temperature:

-4°~140°F (-20°~+60°C)

Flashlight: 25 Lumens

Dimensions: 5.88" x 3.00" x 0.63"

Weight: 0.50 lb

SAFETY INFORMATION

By using the Limitless TotalBoost, you hereby agree that Limitless Innovations, Inc., an Illinois corporation and its affiliates ("Limitless") shall have no liability for any losses associated with property damage, personal injury or loss of life that are incurred by you or by any third party in connection with or relating in any manner whatsoever to your use of the Limitless TotalBoost. By using the Limitless TotalBoost, you hereby agree at all times to comply fully with all safety warnings, operating instructions and general safety information in this user By using the Limitless TotalBoost, you further agree to hold Limitless, (and Limitless' directors, shareholders and employees) in connection with any losses sustained by you (including, without limitation, losses arising in whole or in part from property damage, personal injury or loss of life) relating in any manner whatsoever to your use of the Limitless TotalBoost.

WARNING

- Limitless TotalBoost is NOT a toy and should be kept away from children.
- Do NOT use the Limitless TotalBoost near a magnetic or electric field.
- Do **NOT** use the Limitless TotalBoost in direct sunlight or extreme heat for extended periods of time.
- Do **NOT** use the Limitless TotalBoost if it has been damaged and/or modified.
- Do **NOT** subject the Limitless TotalBoost to harsh chemicals.
- Do **NOT** submerge the Limitless TotalBoost or its accessories in water.
- CAUTION: Risk of fire and burns. Do NOT open, crush, heat above 140° F (60° C) or incinerate. Follow manufacture's instructions.
- Do **NOT** insert any foreign objects into the openings or port of the Limitless TotalBoost.
- Do NOT charge the Limitless TotalBoost in high humidity conditions.
- Do NOT attempt to replace the battery as it is a non-serviceable part.

- Do NOT attempt to disassemble, repair. or open the Limitless TotalBoost or its accessories in any way.
- Do **NOT** paint or apply coatings to the Limitless TotalBoost as you might affect moving parts or damage internal components.
- Do NOT use third party power supplies or non-approved adapters with the Limitless TotalBoost.
- Do **NOT** use at an altitude higher than 6.562 feet (2.000 meters).
- Batteries should be recycled or disposed of, as per state and local guidelines.
- Do **NOT** stare directly into the flashlight.

To view the complete user manual, please scan:



LIMITLESS

All rights reserved. Limitless TotalBoost™, TotalBoost™. and Limitless™ are trademarks of Limitless Innovations, Inc. Design and specifications subject to change without notice. Products may vary from images shown. Accessories sold separately.

LimitlessInnovations.com

Support@LimitlessInnovations.com (855) 843-4828

> Limitless Innovations, Inc. 4800 Metalmaster Wav McHenry, IL 60050

© Limitless Innovations, Inc.













WHAT'S INCLUDED

- (1) Limitless TotalBoost
- (1) Detachable Carrying Strap
- (1) 12" 3-In-1 Type-C to USB Cable
- (1) 12" Type-C to Type-C Cable






COMPONENTS

- 1. Digital Battery Level Indicator
- **2.** Flashlight Power Button
- **3.** Flashlight
- **4.** USB Charging Ports (Output)
- **5.** Type-C Charging Port (Input/Output)
- **6.** Carrying Strap Attachment

12" 3-In-1 Type-C to USB Cable

- **7.** USB Plug
- **8.** Type-C Tip (Power Source)
- **9.** Lightning Adapter Tip
- **10.** Micro Adapter Tip



REMOVING THE STRAP

- Open the threaded section of the Carrying Strap to widen the loop.
- Pull the Carrying Strap through the thread and detach it from the TotalBoost.



HOW TO USE

Getting Started

The TotalBoost will arrive with a partial charge. It is recommended to charge the battery to 100% before use.

Checking the Battery Level

- 1. Press the Flashlight Power Button.
- 2. The current percentage level will display on the digital screen.
- 3. Double click the Flashlight Power Button to turn of the TotalBoost.

How to Recharge the Power Bank:

Plug the Type-C Tip on the 12" 3-In-1 Type-C to USB Cable into the Type-C Input and into a USB charger (not included). The Digital Battery Level Indicator will blink while charging until it reaches 100%.

Using the Flashlight

Press and hold the Power Button for up to 3 seconds to turn the Flashlight on/off.

Using the Power Bank

Select your charging method and connect a compatible charging cable to the TotalBoost and into the charging port on a device. The device will automatically begin to charge.

How to Use the 12" 3-In-1 Type-C to USB Cable

*The Type-C Tip is the power source. The Lightning and Micro adapters will **NOT** charge anything without being connected to the Type-C Tip. See Figure A.

- Choose the charging adapter that is compatible with your device.
- If your device uses the Type-C Adapter, connect it directly to the device.
- If your device uses the Lightning or Micro adapters:
 - A. You must insert the Type-C Tip into the bottom of the adapter.
 - B. Once the Type-C is connected to the respective adapter, plug the adapter into the device.
- 4. Connect the USB Plug on the Charging Cable to a USB Charging Port on the TotalBoost. The device will begin to charge.
- The green icon on the display indicates that a quick-charge compatible device has been connected to the TotalBoost. Please note, some devices may not trigger the green icon, but they are still able to charge on the TotalBoost at the fastest charge that can be accepted by the device.

